



Marflex Building Solutions / 6866 Chrisman Lane / Middletown, OH 45042
 Toll Free: (800) 498-1411 / Main Phone: (513) 422-7285 / Fax: (513) 422-7282
 E-mail: technicalsupport@mar-flex.com
www.MarflexBuildingSolutions.com

This specification specifies Marflex 5000™ Solvent-based Waterproofing Membrane. This product is manufactured by Marflex Building Solutions. Revise section number and title below to suit project requirements, specification practices and section content. Refer to CSI MasterFormat for other section numbers and titles.

This specification utilizes the Construction Specifications Institute (CSI) Manual of Practice, including MasterFormat™, SectionFormat™ and PageFormat™. This is a manufacturer-specific proprietary product specification using the proprietary method of specifying applicable to project specifications and master guide specifications. Optional text is indicated by brackets []; delete optional text in final copy of specification. Specifier Notes typically precede specification text; delete notes in final copy of specification. Trade/brand names with appropriate symbols typically are used in Specifier Notes; symbols are not used in specification text. Metric conversion, where used, is soft metric conversion.

SECTION 07140 FLUID-APPLIED WATERPROOFING

PART 1 GENERAL

1.01 SUMMARY

A. Section Includes: Fluid-Applied Waterproofing.

Specifier Note: Article below may be omitted when specifying manufacturer's proprietary products and recommended installation. Retain Reference Article when specifying products and installation by an industry reference standard. If retained, list standard(s) referenced in this section. Indicate issuing authority name, acronym, standard designation and title. Establish policy for indicating edition date of standard referenced. Conditions of the Contract or Division 1 References Section may establish the edition date of standards. This article does not require compliance with standard, but is merely a listing of references used. Article below should list only those industry standards referenced in this section.

B. Related Sections:

1. Section 033000 – Cast in Place Concrete
2. Section 071000 – Dampproofing and Waterproofing
3. Section 312310 – Building Excavation and Fill
4. Section 334616 – Subdrainage Piping
5. Section 334619 – Underslab Drainage
6. Section 042200 – Masonry
7. Section 076000 – Flashing & Sheet Metal

1.02 REFERENCES

A. American Society for Testing and Materials (ASTM):

1. ASTM C-719 Standard Test Method for Adhesion and Cohesion of Elastomeric Joint Sealants Under Cyclic Movement (Hockman Cycle).
2. ASTM C-836 Standard Specification for High Solids Content, Cold Liquid-Applied Elastomeric Waterproofing Membrane for Use with Separate Wearing Course.
3. ASTM D-2939 Standard Test Methods for Emulsified Bitumens Used as Protective Coatings.
4. ASTM E-96 Standard Test Method for Water Vapor Transmission of Materials.
5. ASTM D-466 Standard Test Method for Films Deposited from Bituminous Emulsions
6. ASTM D-412 Standard Test Method for Vulcanized Rubber and Thermoplastic Elastomers-Tension
7. ASTM D-3274 Standard Test Method for Emulsified Bitumens Used as Protective Coatings

1.03 SUBMITTALS

- A. General: Submit listed submittals in accordance with Conditions of the Contract and Division 1 Submittal Procedures Section.
- B. Product Data: Submit manufacturer's product data and installation instructions.
- C. Quality Assurance/Control Submittals: Submit the following:
 1. Certificates: Submit certificate that applicator complies with requirements of this section.

Specifier Note: Article below should include prerequisites, standards, limitations and criteria that establish an overall level of quality for products and workmanship for this section. Coordinate article below with Division 1 Quality Assurance Section.

1.04 QUALITY ASSURANCE

Specifier Note: Paragraph below should list obligations for compliance with specific code requirements particular to this section. General statements to comply with a particular code are typically addressed in Conditions of the Contract and Division 1 Regulatory Requirements Section. Repetitive statements should be avoided.

- A. Applicator Qualifications: Utilize an applicator trained and approved by the waterproofing manufacturer.
- B. Regulatory Requirements and Approvals: Comply with requirements of the following:
 - 1. ICC Evaluation Service, Inc. (ICC-ES)
 - a. Legacy Report NER-658

Specifier Note: Article below should include special and unique requirements. Coordinate article below with Division 1 Product Requirements Section.

1.05 DELIVERY, STORAGE & HANDLING

- A. General: Comply with Division 1 Product Requirement Section.
- B. Delivery: Deliver materials in manufacturer's original, unopened, undamaged containers with identification labels intact.
- C. Storage and Protection: Store materials protected from exposure to harmful environmental conditions and at temperature and humidity conditions recommended by the manufacturer.

1.06 PROJECT/SITE CONDITIONS

- A. Environmental Requirements: Comply with application temperature range of 0 - 150°F (-18 - 66°C).

1.07 WARRANTY

- A. Manufacturer's material warranty available.

PART 2 PRODUCTS

Specifier Note: Retain article below for proprietary method specification. Add product attributes, performance characteristics, material standards and descriptions as applicable. Use of such phrases as "or equal" or "or approved equal" or similar phrases may cause ambiguity in specifications. Such phrases require verification (procedural, legal and regulatory) and assignment of responsibility for determining "or equal" products.

2.01 FLUID-APPLIED WATERPROOFING

Specifier Note: Paragraph below is an addition to CSI SectionFormat. Retain or delete paragraph below per project requirements and specifier's practice.

- A. Manufacturer: Marflex Building Solutions
 - 1. Contact: 6866 Chrisman Lane, Middletown, OH 45042; Telephone: (800) 498-1411, (513) 422-7285; Fax: (513) 422-7282
 - 2. E-mail: technicalsupport@Mar-flex.com; Website: www.MarflexBuildingSolutions.com
- B. Proprietary Products/Systems should be purchased through an Authorized Dealer of Marflex Products.
- C. Fluid-Applied Waterproofing and related products, including the following:

Specifier Note: Select method of application to suit project requirements and specify below.

- 1. Marflex 5000™ Waterproofing Membrane:
 - a. Material: Polymer Modified Asphalt Membrane
 - b. Color: Black
 - c. Total Solids: 70 - 75%
 - d. Application Method: [Spray] [Brush] [Roll]
 - e. Coverage Rate: 4-gal/100 ft²
 - f. Film Thickness, Dry: 60 mil (1.5 mm) min.
 - g. Total Cure Time: 24 hours
 - h. Weight/Gallon: 7.6 lb (3.4 kg)
 - i. Elongation at 70°F (21°C) (ASTM D-412 Die C): 1725%
 - j. Tensile Strength (ASTM C-719): 48 psi (331 kPa)
 - k. Low Temperature Flexibility at -15°F (ASTM C 719): No cracking
 - l. Crack Bridging (ASTM C-836): 10 cycles without bond failure
 - m. Resistance to Water Flow (ASTM D-466): Bond strength not affected

- n. Water Solubility (ASTM D-2939): No blistering or re-emulsion
- o. Resistance to Hydrostatic Pressure (Federal Spec TT-C-555B, Par.4.4.7.):
 - i. Water Leaks: None
 - ii. Weight Gain: None
- p. Permeability: 0.23 perms (13 ng/(Pa × s × m²).
- q. Water Vapor (ASTM E-96):
 - i. Transmission: 0.11 grains/sf/h.
 - ii. Permeability: 0.23 perms (13 ng/(Pa × s × m²).

Specifier Note: Specify appropriate drainage/insulation board below to suit project requirements.

Specifier Note: Type III DrainCore is designed for flat decking, retaining walls and bridge abutments.

- 2. ShockWave 1 or 2 Foundation Insulation/Drainage Board:
 - a. Material: Closed Cell Foam Board
 - b. Thermal Resistance: 9.0 - 13.50
 - c. Foundation Drainage Rate: Up to 101.11 gal/hr/lin ft
- 3. Geo-Mat™ Plus Drainage Roll:
 - a. Material: High Density Polyethylene (HDPE) drainage rolls with attached polypropylene geotextile mat.
 - b. Foundation Drainage Rate: 30.1 gal/min/ft²
- 4. Type II™ DrainCore Dimpleboard:
 - a. Material: Polystyrene compressed into a moderate-duty dimpled core bonded to a single layer of non-woven filter fabric.
 - b. Foundation Drainage Rate: 21 g/pm/ft width
- 5. 1-3/8" or 2-3/4" QuickSilver™ Foundation Insulation/Drainage Board:
 - a. Material: Expanded Polystyrene with a 1-mil metallic polypropylene laminate on one side and a 1-mil clear laminate on the other side.
 - b. Thermal Resistance: R 2.8 – 10.2
 - c. Foundation Drainage Rate: 11.7 gal/hr/lin.ft.
- 6. Type III DrainCore Decking Drainage:
 - a. Material: Polystyrene compressed into a moderate-duty dimpled core bonded to a single layer of non-woven filter fabric.
 - b. Foundation Drainage Rate: 8.5 g/pm/ft width

Specifier Note: Edit Article below to suit project requirements. If substitutions are permitted, edit text below. Add text to refer to Division 1 Project Requirements (Product Substitutions Procedures) Section.

2.02 PRODUCT SUBSTITUTIONS

- A. Substitutions: No substitutions permitted.

2.03 ACCESSORY MATERIALS

- A. Provide proprietary accessory materials, including the following:

Specifier Note: Specify mastic below to patch cracks, voids and holes in the concrete or masonry walls, which are to receive waterproofing. Marflex 362 Mastic is made of fiberated, trowel grade, asphalt-based mastic, which is fortified with Bio fiber. These materials adhere tightly to form a strong, flexible bond. They may be used in any weather conditions, including applying to damp or cold surfaces, for patching tie holes and honeycombed areas in both rough and smooth masonry surfaces.

- 1. Marflex's 362 Mastic:
 - a. Material: Plastic or resin material compatible with the waterproofing membrane.

Specifier Note: For horizontal application, specify drainage material to remove drainage water.

- 2. Marflex's 12" 523 DrainAway
- 3. Marflex's 12" Connectors

PART 3 EXECUTION

Specifier Note: Article below is an addition to the CSI SectionFormat. Revise article below to suit project requirements and specifier's practice.

3.01 MANUFACTURER'S INSTRUCTIONS

- A. Comply with the most current written installation instructions and recommendations of the waterproofing manufacturer.

3.02 EXAMINATION

- A. Site Verification of Condition:
 - 1. Verify that site conditions are acceptable for application of the waterproofing system.
 - 2. Do not proceed with application until unacceptable conditions are corrected.

3.03 PREPARATION

- A. Surface Preparation:
 - 1. Ensure that the surfaces to receive waterproofing are structurally sound and free of moisture, dust, mud, loose mortar, fins, metal projections or any substances that would be detrimental to the bonding of the membrane to the surface.
 - 2. Remove wall ties.
 - 3. Patch cracks, voids and holes with nonshrink grout or mastic.

Specifier Note: Coordinate article below with manufacturer's recommended application requirements.

3.04 APPLICATION

- A. For vertical application [Spray] [Brush] [Roll] [Trowel] apply a uniform coat of waterproofing to entire wall area. Obtain a seamless membrane free of entrapped gasses, with a minimum dry film thickness of 60 mil (1.5 mm) below-grade wall application.
 - 1. Apply fluid membrane onto footing area a minimum of 4 inches (102 mm) to prevent water pooling.
 - 2. Allow membrane to cure for 24 hours before placing any backfill against the wall.
 - 3. Follow the current installation instructions.
- B. For horizontal application [Spray] [Brush] [Roll] apply a uniform coat of waterproofing to entire wall area. Obtain a seamless membrane free of entrapped gasses, with a minimum dry film thickness of 100 mil (2.5 mm) for Above/At grade application.
 - 1. Allow the fluid membrane to cure out approximately 3-4 hours.
 - 2. Fluid membrane will still be tacky.
 - 3. Install Type III DrainCore following current installation instructions.

3.05 INSULATING/DRAINAGE PANEL INSTALLATION

Specifier Note: Edit, retain or delete paragraphs below to comply with project requirements and specifier practices.

- A. When using the Geo-Mat Plus, install after membrane has been applied. Place and secure to substrate according to manufacturer's current written instructions.
 - 1. While the membrane is still tacky, begin installation at a corner. Install horizontally against the waterproofing membrane with the polypropylene geotextile mat side facing out-ward.
 - 2. Install panels from top of footing extending to finish grade level. If there is overlapping off the membrane once you have reached the grade line, a utility knife or similar tool can be used to cut the rolls to the correct height.
 - 3. For good adherence, apply uniform pressure throughout the surface area, not just the edges and corners.
 - 4. When two edges come together from two separate pieces, overlap the dimples to create a continuous coverage of the wall.
 - 5. Secure the Geo-Mat Plus to the wall with Geo-Mat accessories.
 - 6. If the board overlaps the membrane once you have reached the grade line, a utility knife or similar tool can be used to cut the boards to the correct height.
- B. When using ShockWave, install after membrane has been applied. Place and secure to substrate according to manufacturer's current written instructions.
 - 1. While the membrane is still tacky, starting at a corner with the filter fabric side facing out-ward, install the ShockWave Drainage Board horizontally over the sprayed sections of the wall. The boards should be placed side by side, extending from the top of the footers to finished grade.
 - 2. Apply uniform pressure to the board throughout the surface area, not just the edges and corners. Note: If boards are stacked, maintain a factory-equivalent edge at all seams to ensure proper fit and drainage channel alignment. Using a Geo Clip, secure the ShockWave to the wall at corners and seams.
 - 3. When securing the ShockWave at the top of the boards, place a Geo Clip at each corner making sure that at least two prongs from the Geo Clip is placed in each board. When securing the ShockWave at

- the seems, place a Geo Clip in the middle of the boards making sure that there is one prong in each board.
4. Once the Geo Clips are in place install them using a powder actuated mechanical fastener or concrete nail.
 5. If the board overlaps the membrane once you have reached the grade line, a utility knife or similar tool can be used to cut the boards to the correct height.
- C. When using Type II, install after membrane has been applied. Place and secure to substrate according to manufacturer's current written instructions.
1. While the membrane is still tacky, begin installation at a corner. Install horizontally against the waterproofing membrane with the non-woven filter fabric side facing out-ward.
 2. Install panels from top of footing extending to finish grade level. If there is overlapping off the membrane once you have reached the grade line, a utility knife or similar tool can be used to cut the rolls to the correct height.
 3. For good adherence, apply uniform pressure throughout the surface area, not just the edges and corners.
 4. When two edges come together from two separate pieces, overlap the dimples to create a continuous coverage of the wall.
 5. If needed, secure the panels to the wall using a powder actuated mechanical fastener or concrete nail.
 6. If the board overlaps the membrane once you have reached the grade line, a utility knife or similar tool can be used to cut the boards to the correct height.
- D. When using QuickSilver install after membrane has been applied. Place and secure drainage panels to substrate according to manufacturer's current written instructions.
1. The boards should be placed side by side, extending from the top of the footers to finished grade with the metallic side of the board facing you. Boards must be installed with drainage channels in a vertical position in order to maintain drainage flow. Note: Boards with the shiplap edges should be fitted together to ensure a tight fit.
 2. If needed, secure QuickSilver to the wall using powder actuated mechanical fasteners. Install top fasteners within 4" (102 mm) of the tops of each panel.
 3. If board overlaps the membrane once you have reached the grade line, a utility knife or similar tool can be used to cut the boards to the correct height.
- E. When using Type III for flat decking, begin installation after membrane has been applied. Place draincore to substrate according to manufacturer's current written instructions.
1. Unroll the Type III, placing gray side down against membrane. To keep in place, use double sided tape, adhesives or nails.
 2. For overlaps, place adjacent sections so that the cores abut. Secure fabric overlap at five foot intervals with glue, tape or nails.
 3. Join roll ends by peeling back fabric and removing 4" of core. Place end panels so that cores abut, then glue, tape or nail fabric overlap.
 4. Make cuts for any drains to allow water to be drained.
 5. Allow 24 hour set time.
 6. Pour desired thickness of concrete over the Type III.
- F. Protect installed insulation/drainage panels during subsequent construction
- G. Backfill and Drainage
1. #57 Gravel or equivalent must go no less than 2' high at the base of the foundation and 1' in depth away from the foundation walls.
 2. Adequate interior and exterior foundation drainage at the base of the foundation walls, across any floors or adjacent flower beds must be properly installed and functioning properly.
 3. Backfilling should begin no sooner than 24 hours after the installation of the board, but must be backfilled within 15 days.
- H. 12" 523 DrainAway Vertical Collection System Installation
1. Unroll material along foundation base; adhere to partially cured waterproofing material; use adhesive acceptable to waterproofing material manufacturer for cured waterproofing or other sheet waterproofing not requiring curing.
 2. Install preformed corner fittings at foundation interior and exterior corners. Install outlet fittings where indicated; connect to corrugated drainage pipe if present at time of modular system installation; leave ready for connection to corrugated drainage pipe if not present.

Specifier Note: Coordinate article below with Division 1 Execution Requirements (Cleaning) Section.

3.06 CLEANING

- A. Clean spillage and soiling from adjacent construction using cleaning agents and procedures recommended by manufacturer of affected construction.